Easter Bunny

Scroll saw pattern · 7.5 × 7.5 in (190 × 190 mm) · Print at 100% / Actual size

Black = wood that stays. Cut out every white area inside the design, then cut the outer edge.

1 in check
25.4 mm



Pattern is at full size. Free for personal use and for selling finished pieces; do not share or sell this file. plycutplan.com/scroll-saw-patterns/easter-bunny/